

# **OPERATING MANUAL / INSTRUCTIONS**



# KLASIK SERIES PUSH PULL & SPOOL

PART NUMBER: OM-104A EN

Jinan North welding Tools Co Ltd The North of 308 National Highway, Daqiao Town, Tianqiao Zone, Jinan 250121, Shandong, China



Read and understand this entire Manual and your employer's safety practices before installing, operating, or servicing this Product. While the information contained in this Manual represents the Manufacturer's best judgment, the Manufacturer assumes no liability for its use

### User Manual No: OM-104A EN for: KLASIK Spool and Push-Pull MIG/MAG Manual Welding Torches

KLASIK	Spool and Push-Pull MIG/MAG Manual Welding Torch Model Number
Spool Torch	QLBF-200 III-6E, QLBF-200 III-8E, QLBF-200 III-6T, QLBF-200 III-8T; QLBF-185-6, QLBF-185-8. QTLB-24D-SP-6E, QTLB-24D-SP-8E, QTLB-24D-SP-6T, QTLB-24D-SP-8T. QTLB-36D-SP-6E, QTLB-36D-SP-8E, QTLB-36D-SP-6T, QTLB-36D-SP-8T.
Push-Pull Torch	PG4000-6, PG4045-6, PG4000-8, PG4045-8; PW5000-6, PW5045-6, PW5000-8, PW5045-8. QTLB-24D-6, QTLB-24D-6, QTLB-24D-8, QTLB-24D-8; QTLB-36D-6, QTLB-36D-6, QTLB-36D-8, QTLB-36D-8.

Published by:	Jinan North Welding Tools Co Ltd
	The North of 308 National Highway, Daqiao Town,
	Tianqiao Zone, Jinan 250121, Shandong, China.
Website:	www.northweld.com

Copyright © 2018 by: Jinan North Welding Tools Co. Ltd.

Reproduction of this User Manual, in whole or in part, without written permission of the publisher is prohibited.

The publisher does not assume and hereby disclaims any liability to any party for any loss or damage caused by any error or omission in this User Manual, whether such error results from negligence, accident, or any other cause.

Publication Date: May 2022

Record the following information for Warranty purposes

Place of Purchase:

Purchase Date:



# **Declaration of Conformity**

**Jinan North Welding Tools Co. Ltd.** declares that the product(s) identified in this declaration conform to the essential requirements and provisions of the stated Council Directives and Standards.

Product Description:	Arc Welding Equipment MIG/MAG Manual Welding Spool Torch & Push-Pull Torches
Product Models:	KLASIK SERIES of Spool Torch & Push-Pull MIG/MAG Manual Welding Torches
Manufacturer:	Jinan North Welding Tools Co. Ltd.
Address:	The North of 308 National Highway, Daqiao Town, Tianqiao Zone, Jinan 250121, Shandong, China.

Product Identification:

KLASIK	Spool and Push-Pull MIG/MAG Manual Welding Torch Model Numbers
	QLBF-200 III-6E, QLBF-200 III-8E, QLBF-200 III-6T, QLBF-200 III-8T; QLBF-185-6, QLBF-185-8.
Spool Torch	QTLB-24D-SP-6E, QTLB-24D-SP-8E, QTLB-24D-SP-6T, QTLB-24D-SP-8T.
	QTLB-36D-SP-6E, QTLB-36D-SP-8E, QTLB-36D-SP-6T, QTLB-36D-SP-8T.
Push-Pull	PG4000-6, PG4045-6, PG 000-8, PG4045-8; PW5000-6, PW5045-6, PW5000-8, PW5045-8.
Torch	QTLB-24D-6, QTLB-24D-6, QTLB-24D-8, QTLB-24D-8; QTLB-36D-6, QTLB-36D-6, QTLB-36D-8, QTLB-36D-8.
Council Dire	ectives: • 2006/95/EC Low Voltage Directive
	<ul> <li>2011/65/EU Restriction of the use of certain hazardous substances in electrical and electronic equipment</li> </ul>
Standards:	<ul> <li>GB/T 15579.7-2013 Standardization Administration of China - Arc Welding Equip- ment - Part 7: Torches</li> </ul>

• IEC 60974-7:2013 Arc welding equipment – Part 7: Torches

Signature of Manufacturer's responsible representative:

U

Signature

May 25, 2022

Date

Zhang Jinlu

Name

Manager-Engineering Title

(6

# **Table of Contents**

SECTION 1 – SA	FETY INSTRUCTIONS: Read Before Using this Product	5						
1.01	Arc Welding Hazard Symbols	5						
1.02	Additional Installation, Operation and Maintenance Hazard Symbols	7						
1.03	Read Principal Safety Standards	8						
1.04	California Proposition 65 Warnings	8						
1.05	ELECTRIC and MAGNETIC FIELDS (EMF) Recommendations	8						
SECTION 2 – W	ARRANTY	9						
2.01	Conditions of Intended Use	9						
	TRODUCTION	10						
SECTION S - IN		. 10						
3.UI 2.02	KLASIK TOFCII DESCFIPIIUII	IU 10						
3.02	KLASIK Spool forcies Duty Cycle	10						
3 04	KLASIK Torch Contents	10						
3.05	KLASIK Spool Torch Specifications							
3.06	KLASIK Push-Pull Torch Specifications: QTLB-24D, QTLB-36D	11						
3.07	KLASIK Push-Pull Torch Specifications: PG4000 / PG4045, PW5000 / PG5045	. 11						
SECTION 4 – SP	OOL TOBCH: Installation and Operation	. 12						
4 01	SPAN TARCH' Environmental Limits	12						
4.01	SPOOL TORCH: Oneration Guidelines	12						
4.03	SPOOL TORCH: Connecting Torch Power Pin to MIG Equipment Adaptor	12						
4.04	SPOOL TORCH: Install Welding Wire Spool Then Threading the Welding Wire	13						
4.05	SPOOL TORCH: How to Feed Welding Wire	14						
4.06	SPOOL TORCH: Depress Torch Trigger Switch	15						
SECTION 5 – SP	OOL TOBCH: Wear Parts & Torch Parts	. 16						
5 01	SPINI TORCH: Change Wear Parts	16						
5.01	SPOOL TORCH: Nozzles Contact Tins Contact Tin Holders Gas Diffusers and Liners Parts	16						
5.03	SPOOL TORCH OLBF-200 III: Change Pressure Roll / Drive Roll	19						
5.04	SPOOL TORCH QLBF-185: Change Pressure Roll / Drive Roll	20						
5.05	SPOOL TORCH QTLB-24D / QTLB-36D: Change Pressure Roll / Drive Roll	20						
5.06	SPOOL TORCH QLBF-200 III: Torch Parts	. 21						
5.07	SPOOL TORCH QLBF-185: Torch Parts	22						
5.08	SPOOL TORCH QTLB-24D: Torch Parts	23						
5.09	SPOOL TORCH QTLB-36D: Torch Parts	24						
SECTION 6 – PU	SH-PULL TORCH: Installation and Operation	. 25						
6.01	PUSH-PULL: Environmental Limits	. 25						
6.02	PUSH-PULL: Operation Guidelines	. 25						
6.03	PUSH-PULL TORCH: Connecting Torches Euro Power Pin to MIG Equipment Adaptor	. 25						
6.04	PUSH-PULL TORCH QTLB-24D, QTLB-36D: How to Feed Welding Wire	26						
6.05	PUSH-PULL TORCH PG4000 / PG4045, PW5000 / PW5045: How to Feed Welding Wire	27						
6.06	PUSH-PULL TORCH: Depress Torch Trigger Switch	27						
SECTION 7 – PU	SH-PULL TORCH: Wear Parts & Torch Parts	. 28						
7.01	PUSH-PULL: Change Wear Parts for QTLB-24D, QTLB-36D, PG4000 / PG4045, PW5000 / PW5045	. 28						
7.02	PUSH-PULL: Nozzles, Contact Tips, Contact Tip Holders, Gas Diffusers, and Liners Parts	29						
7.03	PUSH-PULL TORCH QTLB-24D / QTLB-36D: Change Pressure Roll / Drive Roll	31						
7.04	PUSH-PULL TORCH PG4000 / PG4045, PW5000 / PW5045: Change Pressure Roll / Pressure Arm Assy	31						
/.U5 7 06	ГООП-FULL: UNANGING TORCH UADIE LINER	. 32 22						
/.UO 7 N7	PUSH-PULL TURCH ATT R-36D. Torch Parte	JJ 2/1						
7 08	PUSH-PULL TORCH PG4000 / PG4045: Torch Parts	. 35						
7.09	PUSH-PULL TORCH PW5000 / PW5045: Torch Parts							
SECTION O - IM								
SECTION 9 – RC	UTINE SERVICE and MAINTENANCE	. 39						
SECTION 10 – C	IRCUIT DIAGRAMS FOR SPOOL & PUSH-PULL TORCHES	. 39						

# **SECTION 1 –** SAFETY INSTRUCTIONS: Read Before Using this Product



DANGER! - Protect yourself and others around you from possible serious injury or death.

1) Read, follow, and understand this User Manual before installing, operating, or servicing this Product. 2) Pacemaker wearers keep away until consulting your doctor. 3) Have all installation, operation, maintenance, and repair work performed only by Suitably Trained and Qualified Tradesperson. 4) Keep children away. 5) Do not lose these instructions.

6) When shipped, ownership is passes to the purchaser upon receipt from the transportation company. Accordingly, claims for component damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

### " NOTE:" Provides information regarding operating recommendations for this Product.

Product and processes can cause serious injury or death, or damage to other equipment or property, if the operator does not strictly observe all safety instructions and take precautionary actions.

Anyone not extensively trained in welding and cutting practices should not attempt to weld or cut metal.

Safe practices are outlined in American National Standard Z49.1 entitled: <u>SAFETY IN WELDING AND CUTTING</u>. This publication and other guides to what you should learn before using this product are listed at the end of these safety instructions.

### 1.01 Arc Welding Hazard Symbols



#### ELECTRIC SHOCK can kill

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit are electrically live whenever the output is on. DO NOT WORK ALONE! The input power circuit and Power Source internal circuits are also electrically live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded welding equipment is a hazard.

- Do not touch live electrical parts.
- Beware of electric shock from wiring.
- Keep all panels and covers securely in place.
- Wear dry, hole-free insulating gloves, and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present:
- In damp locations or while wearing wet clothing.
- On metal structures such as floors, gratings, or scaffolds.
- When in cramped positions such as sitting, kneeling, or lying.
- When there is a high risk of unavoidable or accidental contact with the workpiece or ground.
- For these conditions, use the following equipment:
- 1) A semiautomatic DC constant voltage (wire) welder, or
- A DC manual (stick) welder. In most situations a DC welder is recommended.
- Disconnect input power or stop engine before installing or servicing this Product. Lockout/Tagout input power according to OSHA 29 CFR 1910.147.
- Properly install and ground this Power Source according to its User Manual and national, state, and local codes.
- Use only well-maintained equipment. Repair or replace damaged parts at once.
- Do not wrap cables around your body.
- Always verify the Input Power Cord ground check and be sure that Input Power Cord ground wire is properly connected to ground terminal in disconnect box or that Input Power Cord plug is connected to a properly grounded receptacle outlet.

- When making input connections, attach proper grounding conductor first. DOUBLE CHECK ALL CONNECTIONS.
- Keep all electrical Power Cords dry, free of oil and grease, and protected from hot metal, sparks, and sharp metal edges.
- Frequently inspect Input Power Cord and ground conductor for damage or bare wiring. Replace immediately if damage, bare wiring can kill.
- Turn off all equipment when not in use. Disconnect power to equipment if it will be left unattended or out of service.
- Use fully insulated Torch. Never dip Torch in water to cool it or lay it down on the ground or the work surface. Do not touch Torches connected to two Power Sources at the same time or touch other people with the Torch or electrode.
- Do not use worn, damaged, undersized, repaired or poorly spliced cables.
- Ground the work piece to a good electrical (earth) ground.
- Do not touch electrode while in contact with the work (ground) circuit.
- In confined spaces or damp locations, do not use a welder with AC output unless it is equipped with a voltage reducer. Use equipment with DC output.
- Wear a safety harness to prevent falling if working above floor level.
- Do not touch electrode holders connected to two Power Sources at the same time as double open-circuit voltage will be present.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal. Disconnect cable for process not in use.
- Use ground-fault circuit interrupter (GFCI) protection when operating auxiliary equipment in damp or wet locations.

#### FLYING METAL or DIRT can injure eyes

Welding, chipping, wire brushing, and grinding cause sparks and flying metal.

- Welding slag can be thrown off welds as they cool down.
- Wear approved safety glasses with side shields even under your welding helmet.

#### HOT PARTS can burn



Nozzles, contact tips, gas diffuser welded parts, cut metal, or ground clamp can cause burn bare skin when hot.

- Do not touch hot parts with bare skin.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.

# SAFETY INSTRUCTIONS



### ARC RAYS can injure eyes and burn skin

Arc rays from the welding process produce intense heat and strong ultraviolet rays that can burn eyes and skin.

- Wear approved safety glasses. Side shields recommended.
- Wear a welding helmet fitted with a proper shade of filter (see ANSI Z49.1 listed in Safety Standards) to protect your face and eyes when welding or watching.
- Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (wool and leather) and foot protection.



#### NOISE can damage hearing

- Noise from some processes can damage hearing.
- Use approved ear plugs or earmuffs for high noise levels environments.



#### FLYING SPARKS can injure

Flying sparks and hot metal can cause injury. Chipping and grinding cause flying metal.

• Wear proper body protection to protect skin.

- Wear approved face shield or safety goggles. Side shields are recommended.
- Sparks can cause fire, remove all flammable materials within 35 ft (10.7 m) of the working zone.



#### **EQUIPMENT OVERHEATING**

Power Source casing, terminals, cables, ground clamp, electrode stub or torch parts can cause inquiry when overheated.

- Allow cooling period before touching MIG Torch.
- Allow cooling period; follow rated duty cycle of MIG Torch.
  - Reduce amperage and/or arc on time before starting to weld again.
- Do not block or filter air vent to Power Source.



#### **BUILDUP OF GAS can injure or kill** Shielding GAS used for wire welding can

cause asphyxiation or death in confined places.

- Shut off compressed shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air supplied respirator.



#### FUMES and GASES can be hazardous

FUMES and GASES can be hazardous to your health. Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local exhaust at the arc to remove welding fumes and gases.
- If ventilation is poor, use an approved air-supplied respirator.
- Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instruction for consumables, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have an observer trained in rescue and emergency procedures to monitor the person in a confined space. Shielding gases used for welding can displace air causing injury or death. Be sure the breathing air is safe.

- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapours to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



#### **MOVING PARTS can cause injury**

Moving parts, such as fans, drive gears, rotating wire spools, rotors, and belts can cut fingers and hands and catch loose clothing.

- Keep all doors, panels, covers, and guards closed and securely in place.
- Switch OFF Power Source before installing or connecting it.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Have only suitably Trained and Qualified Tradesperson remove guards or covers for maintenance and troubleshooting, as necessary.
- To prevent accidental starting during servicing, disconnect Power Source from power receptacle or disconnect negative battery cable from battery.
- Reinstall panels or guards and close doors when servicing is finished and before starting engine.



#### ELECTRIC and MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices

Consult your doctor and the Implanted Medical Device manufacturer before going near arc welding, spot welding, gouging or plasma arc cutting.

Wearers of Pacemakers and other Implanted Medical Devices should keep away.



### SHIELDING GAS CYLINDERS can explode

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process; be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, and arcs.
- Install and secure cylinder(s) in an upright position by chaining cylinder(s) to a stationary support or equipment cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never allow a welding electrode to touch any cylinder.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.



WELDING WIRE can cause injury

Welding wire can cause injuries to hands, ears, eyes, etc.

- Do not depress Torch Trigger or commence welding process until it is safe to do so.
- Do not point the end of the MIG Torch near any part of your body, other people, or any metal when threading the welding wire thru the MIG Torch.

s, parts • Wearers of Pacemake keep away.

# SAFETY INSTRUCTIONS

Eye protection filter shade selector numbers for welding (goggles or helmet)								
Welding operation Arc Amperage (Amps) Minimum Filter Shade Number Suggested ^ Filter Shade								
Gas Metal Arc Welding (GMAW)	Less than 60	7	7					
and	60 - 160	10	11					
allu	160 – 250	10	12					
Flux Cored Arc Welding (FCAW)	250 - 550	10	14					

<sup>^</sup> As a rule of thumb, start with a shade that is too dark to see the weld zone. Then go to a lighter shade which gives sufficient view of the weld zone without going below the minimum. This Lens Shade Selector Guide was adapted from ANSI Z49.1, 2012.



#### WELDING can cause fire or explosion

Sparks and spatter fly off from the welding arc. The flying sparks and hot molten metal, weld spatter, hot work piece and hot equipment can cause fires and burns.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Accidental contact of electrode or welding wire to metal objects can cause sparks, overheating, fire, or explosion. Check that the area is safe before doing any welding.

- · Protect yourself and others from flying sparks and hot metal.
- · Do not weld where flying sparks can strike flammable material.
- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on containers that have held combustibles or on closed containers such as tanks, drums, or pipes unless they are properly prepared according to AWS F4.1 and AWS A6.0.

- Do not weld where the atmosphere contains flammable dust, gas, or liquid vapours (gasoline for example).
- Connect work cable to the work as close to the welding area as practical to prevent welding amperage from travelling long, possibly unknown paths and causing electric shock and fire hazards.
- Use only correct fuses or circuit breakers. Do not oversize or bypass
  them.
- Cut off welding wire at contact tip when not in use.
- Wear body protection made from durable, flame-resistant material (leather, heavy cotton, wool). Body protection includes oil-free clothing such as leather gloves, heavy shirt, cuff less trousers, high shoes, and a cap.
- Remove any combustibles, such as butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.
- Read and understand the Safety Data Sheets (SDSs) and the manufacturer's instructions for adhesives, coatings, cleaners, consumables, coolants, degreasers, fluxes, and metals.

### 1.02 Additional Installation, Operation and Maintenance Hazard Symbols



### **READ USER MANUAL**

Read and follow all Power Source labels and User Manual carefully before installing, operating, or servicing the Power Source.

- Read the safety information at the beginning of the manual and in each section.
- Perform installation, maintenance, and service according to the User Manual, industry standards, and national, state, and local codes.



### IMPROPER INSTALLATION can cause fire

Improper equipment installation can cause fire.

- Do not install or place Power Source on, over, or near combustible surfaces.
- Do not install Power Source near flammables.
- Do not overload building wiring; be sure Input Power Supply system is properly sized, rated, and protected for weld system.



#### **ARC WELDING can cause interference**

Arc welding produces electromagnetic energy that can interfere with sensitive electronic equipment.

- Electronic equipment that can be affected are computers, telecommunication equipment, and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.

- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this Power Source is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the Power Source, using shielded cables, using line filters, or shielding the work area.



### COMPRESSED AIR can injure or kill. Whipping air hoses can injure.

A concentrated stream of air at high pressure and high speed that can cause serious injury you or people around you.

- Do not direct air stream toward self or others.
- Wear protective equipment such as safety glasses, hearing protection, leather gloves, heavy shirt / trousers, steel toe boots, and a cap when working on compressed air system.
- Release air pressure from air system / air tools before servicing, adding, or changing attachments.
- Turn off and lockout / Tagout air compressor, release air pressure from system and be sure air pressure cannot be accidentally reapplied before working on compressed air system.
- Relieve air pressure before disconnecting or connecting air lines.
- Check compressed air system components and all connections and hoses for damage, leaks, and wear before operating unit.
- Use soapy water to search for leaks; never use bare hands. Do not use equipment if leaks are found.

# SAFETY INSTRUCTIONS



### FALLING EQUIPMENT can injure

Use designated lifting device on power source to lift the power source only, NOT cart/running gear, gas cylinders, or any other accessories

Use lifting equipment of adequate capacity to lift and support power source.

### 1.03 Read Principal Safety Standards

<u>Safety in Welding, Cutting, and Allied Processes</u>, ANSI Standard Z49.1, is available as a free download from the American Welding Society at (Website: www.aws.org).

<u>Safe Practices for the Preparation of Containers and Piping for Welding</u> <u>and Cutting</u>, American Welding Society Standard AWS F4.1, from Global Engineering Documents (Website: www.global.ihs.com).

<u>Safe Practices for Welding and Cutting Containers that have Held Com-</u> <u>bustibles</u>, American Welding Society Standard AWS A6.0, from Global Engineering Documents (Website: www.global.ihs.com).

<u>National Electrical Code</u>, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (Website: www.nfpa.org).

<u>Safe Handling of Compressed Gases in Cylinders</u>, CGA Pamphlet P-1, from Compressed Gas Association, 14501 George Carter Way, Suite 103, Chantilly, VA 20151 (website: www.cganet. com).

- If using lift forks to move power source, be sure forks are long enough to extend beyond opposite side of power source.
- Keep cables and Power Cords away from moving vehicles when working from an aerial location.
- Follow the guidelines in the *Applications Manual for the Revised NIOSH Lifting Equation* [DHHS (NOISH) Publication No. 94–110] when manually lifting heavy parts or Power Source.

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Mississauga, Ontario, Canada L4W 5NS (Website: www.csagroup.org).

Safe Practice for Occupational and Educational Eye and Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 25 West 43rd Street, New York, NY 10036 (Website: www.ansi.org). Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (Website: www.nfpa.org).

OSHA. Occupational Safety and Health Standards for General Industry,

Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, (Website: www.osha.gov).

<u>Applications Manual for the Revised NIOSH Lifting Equation</u>, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30329-4027 (Website: www.cdc.gov/NIOSH).

### 1.04 California Proposition 65 Warnings



This product contains chemicals, including lead, or otherwise produces chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after handling. (California Health & Safety Code 25249.5 et seq.)

Welding and cutting equipment produce fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. Wear an approved air-supplied respirator for welding and cutting. (California Health & Safety Code Section 25249.5 et seq.)

### 1.05 ELECTRIC and MAGNETIC FIELDS (EMF) Recommendations

Consult your doctor and the Implanted Medical Device manufacturer before going near arc welding, spot welding, gouging, or plasma arc cutting.

EMF is produced around welding cables / accessories during the welding operation and can interfere with some medical implants such as pacemakers. All Welding Operators should use the following procedures in order to minimize exposure to EMF when welding.

- Keep electrode / ground cables together by twisting or taping them together.
- Keep electrode / ground cables away from your body.
- Do not place your body in between the electrode and ground cables.
- Do not coil or drape cable around the body.
- Keep Power source and accessories as far away from your body as possible.
- Do not weld whilst carrying the Power source or accessories.
- Connect the ground clamp to the workpiece as close as possible to the weld zone.

# **SECTION 2 –** WARRANTY



The MIG/MAG Manual Welding Torch is safe and reliable in operation when handled, installed, and maintained by suitably Trained and Qualified Tradesperson.

JINAN NORTH WELDING TOOLS products are meticulously checked during and at completion of manufacture. JINAN NORTH WELDING TOOLS guarantees that each product is free from material defects and workmanship at the time of dispatch and functions according to its intended use.

JINAN NORTH WELDING TOOLS provides warranty on material defects and workmanship according to national or state legal requirements.

Contact Tips, Nozzles, and Liners (consumables) are exempt from this warranty.

The warranty does not cover any damages or functional defects resulting from:

- Overloading, abusing, or diverting from intended use of the product.
- Collisions or accidents.
- Non-compliance with instructions stated in this document.
- Improper installation or assembly.
- Insufficient maintenance.
- Modifying the product from its original state.
- Chemical influences.
- Normal wear and tear.

JINAN NORTH WELDING TOOLS assumes no liability other than for replacement or repair of faulty parts.

JINAN NORTH WELDING TOOLS makes no other warranty of any kind, expressed or implied, including, but not limited to the warranties of merchantability, or fitness for any purpose. JINAN NORTH WELDING TOOLS shall not be liable under any circumstances to Buyer, or to any person who shall purchase from Buyer, for damages of any kind, including, but not limited to any direct, indirect incidental or consequential damages or loss of production or loss of profits resulting from any cause whatsoever, including, but not limited to any delay, act, error, or omission of JINAN NORTH WELDING TOOLS.

Genuine JINAN NORTH WELDING TOOLS parts must be used for safety and performance reasons, or the warranty becomes invalid. Warranty shall not apply if accident, abuse, or misuse damages of a product, or if a product is modified in any way except by authorized JINAN NORTH WELDING TOOLS personnel.

### 2.01 Conditions of Intended Use

- This product is intended for industrial and commercial use and must only be utilized by suitably trained personnel. JINAN NORTH WELDING TOOLS is not liable for any damage or accidents resulting from improper usage.
- The instructions for installation, operation and maintenance described in this document must be followed.
- The MIG/MAG Manual Welding Torch must only be installed, operated, and serviced by suitably Trained and Qualified Tradesperson. The installation, operation, and maintenance regulations detailed in this manual are to be followed.
- The MIG/MAG Manual Welding Torch must solely be used for the intended purpose by the user within the Torches technical specifications and with an automated welding system. The type of Torch must be selected to suit the welding task.
- The MIG/MAG Manual Welding Torch was designed for use as a complete system. The incorporation of components from other manufacturers into the system is not permissible.
- The product must be kept dry and protected from humidity when transported, stored, or used.
- The system is designed for environmental temperature range from 5 °C to 40 °C (41 °F to 104 °F). In case these limits are exceeded, specific action is needed.

# SECTION 3 - INTRODUCTION

### 3.01 KLASIK Torch Description

These air-cooled or water-cooled Spool / Push-Pull MIG/MAG Manual Welding Torches are designed for hand Metal Inert Gas welding (MIG) and Metal Active Gas welding (MAG) welding using MIG/MAG welding Power Source.

The Torches consist of a variety design elements:

- 1. CNC machined tips and gas diffusers are 100% compatible with OEM MIG Torches.
- 2. Ergonomic, solid handle design.
- 3. Positive grip Trigger Button with long life contacts.
- 4. Heavy Duty insulated metal jacketed swan neck with high conductivity inner copper tube.
- 5. Cable supported by steel spring to reduce hand fatigue. These elements create a very reliable and long-lasting Torch system with minimal maintenance.

The JINAN NORTH WELDING TOOLS ordering numbers, available accessories, spare parts, and wear parts are found within this User Manual.

3.02 KLASIK Spool Torches Duty Cycle

The MIG/MAG Manual Welding Spool Torches rated duty cycles is a statement of the time it may be operated at its rated welding amperage without exceeding the temperature limits of the component parts.



### 3.03 KLASIK Push-Pull Torches Duty Cycle

The MIG/MAG Manual Welding Push-Pull Torches rated duty cycles is a statement of the time it may be operated at its rated welding amperage without exceeding the temperature limits of the component parts.



- All KLASIK Torches come complete with:
- MIG/MAG Manual Welding Torch
- Contact Tip
- Nozzle
- User Manual No: OM-104A EN

**NOTE 1:** JINAN NORTH WELDING TOOLS reserves the right to change, improve or revise the specifications or design of this product without prior notice. Such updates or changes do not entitle the buyer of this Product previously sold or shipped to the corresponding changes, updates, improvements, or replacement. The values specified in the table above are nominal parameters. An individual Torch may differ from the above specifications due to in part, but not exclusively, to any one or more of the following variations or changes in manufactured components, installation location/conditions.

#### 3.05 KLASIK Spool Torch Specifications Refer to NOTE 1 on Page 10 QTLB-36D-SP-6E. Part Numbers QLBF-200 III-6E, QI BF-185-6 OTI B-24D-SP-6F QLBF-200 III-8E, QLBF-185-8 QTLB-24D-SP-8E. QTLB-36D-SP-8E QTLB-24D-SP-6T, QTLB-36D-SP-6T, QLBF-200 III-6T, QTLB-36D-SP-8T QLBF-200 III-8T QTLB-24D-SP-8T Torch Length (m) 6 = 6 m, 6 = 6 m, 6 = 6 m, 6 = 6 m.8 = 8 m 8 = 8 m 8 = 8 m 8 = 8 m E = Euro Fitting, 13mm Diameter Hole Lug, Torch Power Connector E = Euro Fitting, E = Euro Fitting, T = Tweco Fitting 5mm ID Hose & 4 Pin Plug T = Tweco Fitting T = Tweco Fitting Swan Neck Angle (°) 180 180 180 or 45 180 or 45 Wire Size Range (mm) 0.6-1.0 0.8-0.9 0.6-1.2 0.8-1.2 Standardization Administration of China -Arc Welding Equipment - Part 7: Torches GB/T 15579 7-2013 IEC Standard for Safety – Arc Welding IEC 60974-7:2019 Equipment - Part 7: Torches **Cooling Method** Air-Cooled Air-Cooled -10 °C to +40 °C Operating Temperature Range (+14 °F to +104 °F) Storage/Transportation -25 °C to +55 °C (-13 °F to +131 °F) Temperature Range **Relative Air Humidity** 0% to 90% (at +20 °C ambient air temperature) **During Operating** Welding Power Rating for MIG/MAG Manual Welding Torch [+40 °C Air Temperature] Rated Amps / Duty Cycle using: 180A/60% 200A/60% CO<sub>2</sub> Shielding Gas 200A/60% 350A/60% 160A/60% 300A/60% Mixed Shielding Gas 160A/60% 160A/60% MIG/MAG Torch Maximum Voltage 113 VDC (Peak Welding Voltage) 3.06 KLASIK Push-Pull Torch Specifications: QTLB-24D, QTLB-36D Refer to NOTE 1 on Page 10 QTLB-24D-6 QTLB-24D-8 QTLB-36D-8 Part Number QTLB-36D-6 Torch Length 8 = 8 m 6 = 6 m8 = 8 m6 = 6 mEuro Fitting Torch Power Connector Euro Fitting Swan Neck Angle (°) 180 or 45 180 or 45 Wire Size Range (mm) 0.8-1.2 0.8-1.2 Standardization Administration of China -Arc Welding Equipment - Part 7: Torches GB/T 15579.7-2013 IEC Standard for Safety - Arc Welding Equipment - Part 7: Torches IEC 60974-7:2019 Cooling Method Air-Cooled Air-Cooled Air-Cooled Air-Cooled Operating Temperature Range -10 °C to +40 °C (+14 °F to +104 °F) Storage/Transportation -25 °C to +55 °C (-13 °F to +131 °F) **Temperature Range** Relative Air Humidity 0% to 90% (at +20 °C ambient air temperature) During Operating Welding Power Rating for MIG/MAG Manual Welding Torch [+40 °C Air Temperature] Rated Amps / Duty Cycle using CO<sub>2</sub> Shielding Gas 200A/60% 350A/60% Mixed Shielding Gas 160A/60% 300A/60% MIG/MAG Torch Maximum Voltage 113 VDC (Peak Welding Voltage) Refer to NOTE 1 on Page 10 3.07 KLASIK Push-Pull Torch Specifications: PG4000 / PG4045, PW5000 / PG5045 PW5000-6 Part Number PG4000-6 PG4045-6 PW5045-6 PG4000-8 PG4045-8 PW5000-8 PW5045-8 Torch Length 6 = 6 m6 = 6 m 6 = 6 m6 = 6 m8 = 8 m 8 = 8 m8 = 8 m 8 = 8 m Torch Power Connector Euro Fitting Euro Fittina 180 45 180 45 Swan Neck Angle (°) Wire Size Range (mm) 0.8-1.2 0.8-1.6 Standardization Administration of China -GB/T 15579.7-2013 Arc Welding Equipment - Part 7: Torches IEC Standard for Safety - Arc Welding Equipment - Part 7: Torches IEC 60974-7:2019 **Cooling Method** Air-Cooled Air-Cooled Water-Cooled Water-Cooled Operating Temperature Range -10 °C to +40 °C (+14 °F to +104 °F Storage/Transportation -25 °C to +55 °C (-13 °F to +131 °F) Temperature Range Relative Air Humidity 0% to 90% (at +20 °C ambient air temperature) **During Operating**

# **SECTION 4 –** SPOOL TORCH: Installation and Operation

#### 4.01 SPOOL TORCH: Environmental Limits 4.02 SPOOL TORCH: Operation Guidelines These air-cooled MIG/MAG Manual Welding Torches are Be sure to locate the MIG/MAG equipment according to designed for use in environments where: the following guidelines: Operating temperature range is -10 °C to +40 °C In areas, free from moisture and dust. (+14 °F to +104 °F) In areas, free from oil, steam, and corrosive gases. Relative air humidity during operating is 0% to 90% @ In areas, not subjected to abnormal vibration or shock. + 20 °C ambient air temperature In areas, not exposed to direct sunlight or rain. Torch installation must be **Disconnect Power to** Flying metal or FUMES and Shielding Moving parts Sparks, weld spatter or Improper instal Read User done by a suitably Trained MIG/MAG equipment. Elec dirt can injure GAS can be hazardous can cause inhot work piece can lation can cause Manual. and Qualified Tradesperson tric shock can kill. to your health. cause fires and burns eves. iurv fire. Genuine JINAN NORTH WELDING TOOLS parts must be used for safety and performance reasons, or the warranty becomes invalid. Inspect all parts for transportation damage. Do not use damaged parts. 4.03 SPOOL TORCH: Connecting Torch Power Pin to MIG Equipment Adaptor For Spool Torches QLBF-200 III-6E, QLBF-200 III-8E, QTLB-24D-SP-6E, QTLB-24D-SP-8E, QTLB-36D-SP-6E, QTLB-36D-SP-8E. Euro Power Pin Connector Block to Euro Style Adaptor a) Disconnect Power to the MIG/MAG equipment. b) Align Euro Power Pin Connector Block with Euro Torch Adaptor then insert it. Euro Torch Adaptor Euro Power Pin Connector Bloc c) Secure tighten the Connector Nut into the Euro Adaptor. d) Connect the Multi-Pin Plug to the MIG/MAG equipment Control Socket. Connector Nut Control For Spool Torches QLBF-200 III-6T, QLBF-200 III-8T, QTLB-24D-SP-6T, QTLB-24D-SP-8T, QTLB-36D-SP-6T, QTLB-36D-SP-8T. Tweco® Power Pin Connector Block to Tweco Style Adaptor a) Disconnect Power to the MIG/MAG equipment. Tweco<sup>®</sup> Style b) Insert the Tweco Power Pin into the Tweco Torch Adaptor to shoulder then se-Power Pin Connector cure using mechanical means as described in MIG/MAG equipment user man-Torch Adaptor ual c) Connect the Multi-Pin Plug to the MIG/MAG equipment Control Socket. Contro For Spool Torches QLBF-185-6, QLBF-185-8. Spool Torch is Hard Wired to MIG/MAG equipment a) Disconnect Power to the MIG/MAG equipment. b) Refer to the MIG/MAG equipment Operating Manual to identify the connection points for the 4-pin plug, power cable with 13mm lug, and 5mm (inside diameter) gas hose. c) Connect power cable with 13mm lug to the MIG/MAG equipment Positive Weld Terminal as described in the MIG/MAG equipment Operating Manual. d) Connect 5mm (inside diameter) gas hose to the MIG/MAG equipment gas hose as described in the MIG/MAG equipment Operating Manual.

e) Connect the Multi-Pin Plug to the MIG/MAG equipment Control Socket.

### **SPOOL TORCH: Installation and Operation**



# **SPOOL TORCH: Installation and Operation**



# **SPOOL TORCH: Installation and Operation**



### 4.06 SPOOL TORCH: Depress Torch Trigger Switch



MODEL: QLBF-185

Torch Trigger Switch (9) – When depressed, the welding power is energized, Welding Wire (if fitted) is driven thru the Spool Swan Neck and shielding gas flows (if gas is connected MIG/MAG equipment and turned on) out of the Swan Neck.



DO NOT put Spool Torch near your ears or eyes when the **Torch Trigger (9)** is depressed as **Welding Wire** will rapidly exit the Contact Tip then the Nozzle and will cause serious to your ears, eyes, or skin.



Touching **Welding Wire** when electrically alive may cause fatal shocks or severe burns.



Always wear Safety glass when operating or near MIG/MAG equipment.





5.02 SPOOL TORCH: Nozzles, Contact Tips, Contact Tip Holders, Gas Diffusers, and Liners Parts

OZZLES							
						81-200 - 185 8-240-58 - 58-58	Product
Part Number	Shape	Materia	ΦA mm	ФВ mm	C mm	dr dr dr dr	pettie
EA1212	Con <sup>°</sup> cal	Copper	12		53	•	ΦΑ ΦΒ
186405		Copper			-	•	
EA22125	Con <sup>°</sup> cal	Copper	12.5		63	•	
EA3216	Conical	Copper	16		84	•	

5.02 SPOOL TORCH: Nozzles, Contact Tips, Contact Tip Holders, Gas Diffusers, and Liners Parts



5.02 SPOOL TORCH: Nozzles, Contact Tips, Contact Tip Holders, Gas Diffusers, and Liners Parts

G	GAS DIFFUSERS										
				2 7-8			OLP	5F 200 185	8-240-5P	2	Product picture
ľ	Part Number	Shape	Material	A mm	Bmm	C mm	ŭ				 c
J	186409		ceram <sup>°</sup> c	-	-	-	(				A B SUSS
	ED2001	-	ceram <sup>°</sup> c	-	-	20					
	ED3002	-	DMC	-	-	32.5					
L	INERS										
								5-200 5-185	8-24D-58	?	Product
ł	Part Number		Material	Wire Size ΦA in/mi	m Length B	ft meters	OL	2. 01 p. 011	" OTL		 picture
	LWR11170										
l	206363										
	LTR21134										
	LTR21142										
	LTR31160										
	LTR31168										

### 5.03 SPOOL TORCH QLBF-200 III: Change Pressure Roll / Drive Roll



### CHANGE Drive Roll (5)

- a) Disconnect Power to the MIG/MAG equipment.
- b) **Press Button** to lift the **Spool Cover** up to expose the Wire Drive Mechanism.
- c) Remove the Welding Wire Spool by:
  K) Hold Wire against the Spool.
  L) Cut Wire between the Spool & Inlet Guide.
  M) Put Cut Wire End from Spool into hole.
  N) Unscrew the Locking Screw.
  - 0) Pull the Welding Wire End out of the Swan Neck.
- d) Rotate the **Pressure Arm Bolt (8)** counter-clockwise to release the tension on the **Pressure Arm Assy**.
- e) Remove the **Pressure Arm Assy** by removing **Circlip (1)** using a suitable tool.
- f) Unscrew Allen Key Grub Screw (6) then slide Drive Roll
   (5) off the Drive Shaft.
- g) Fit a new **Drive Roll (5)** then re-assemble the Spool

### CHANGE Pressure Roll (4)

- a) Disconnect Power to the MIG/MAG equipment.
- Press Button to lift the Spool Cover up to expose the Wire Drive Mechanism.
- c) Remove the Welding Wire Spool by:
  K) Hold Wire against the Spool.
  L) Cut Wire between the Spool & Inlet Guide.
  M) Put Cut Wire End from Spool into hole.
  N) Unscrew the Locking Screw.
  O) Pull the Welding Wire End out of the Swan Neck.
- d) Rotate the **Pressure Arm Bolt (8)** counter-clockwise to release the tension on the **Pressure Roll Bearing (4)**.
- e) Remove the **Pressure Arm Assy** by removing **Circlip (1)** using a suitable tool.
- f) Remove the **Circlip (2)** using a suitable tool.
- g) Remove the **Roll Shaft (3)** then slide out the **Pressure Roll (4)**.
- h) Fit a new **Pressure Roll (4)** then re-assemble the Spool Torch.

### 5.04 SPOOL TORCH QLBF-185: Change Pressure Roll / Drive Roll





### CHANGE Drive Roll (8)

- a) Disconnect Power to the MIG/MAG equipment.
- b) Unscrew Handle Nut (1), and 3 × Handle Screws (2).
- c) Wiggle the Handle Half (3) away from the Spool Torch.
- d) Unscrew and remove Screw (4) and Washer (5) from the Drive Shaft.
- e) Push down on the red **Pressure Roll Release Button (10)** then slide the **Drive Roll (8)** off the **Drive Shaft. Do NOT** lose the **Drive Key (9)**.
- f) Fit a new Drive Roll (8) and then re-assemble the Spool Torch. Note: Ensure the Drive Key (9) is fitted into the slot of the Drive Shaft then line up the slot in the Drive Roll (8) with the Drive Key (9).

### **CHANGE Pressure Roll (6)**

- a) Disconnect Power to the MIG/MAG equipment.
- b) Unscrew Handle Nut (1), and 3 x Handle Screws (2).
- c) Wiggle the Handle Half (3) away from the Spool Torch.
- d) Push down on the red Pressure Roll Release Button (10) then unscrew the Screw (4) to remove the Washer (5), Pressure Roll (6), and Bearing (7) from the Pressure Mechanism. Do NOT lose the Bearing (7).
- e) Fit a new Pressure Roll (6) and then re-assemble the Spool Torch.

### 5.05 SPOOL TORCH QTLB-24D / QTLB-36D: Change Pressure Roll / Drive Roll





### CHANGE Drive Roll (8)

- a) Disconnect Power to the MIG/MAG equipment.
- b) Unscrew Handle Nut (1), and 3 × Handle Screws (2).
- c) Wiggle the Handle Half (3) away from the Spool Torch.
- d) Unscrew and remove Screw (4) and Washer (5) from the Drive Shaft.
- Push down on the red Pressure Roll Release Button (10) then slide the Drive Roll (8) off the Drive Shaft. Do NOT lose the Drive Key (9).
- f) Fit a new Drive Roll (8) and then re-assemble the Spool Torch. Note: Ensure the Drive Key (9) is fitted into the slot of the Drive Shaft then line up the slot in the Drive Roll (8) with the Drive Key (9).

### **CHANGE Pressure Roll (6)**

- a) Disconnect Power to the MIG/MAG equipment.
- b) Unscrew Handle Nut (1), and 3 x Handle Screws (2).
- c) Wiggle the Handle Half (3) away from the Spool Torch.
- d) Push down on the red Pressure Roll Release Button (10) then unscrew the Screw (4) to remove the Washer (5), Pressure Roll (6), and Bearing (7) from the Pressure Mechanism. Do NOT lose the Bearing (7).
- e) Fit a new  $\ensuremath{\text{Pressure Roll}}$  (6) and then re-assemble the Spool Torch.





#### 5.08 SPOOL TORCH QTLB-24D: Torch Parts 38 Ó 26 17 18 wear parts page 16 19 20 25 23 27 15 28 29 G 30 26 31 Model 6M QTLB-24D-SP-6E QTLB-24D-SP 欧式接头 Welding Gun c/w Euro Fitting 8M QTLB-24D-SP-8E 6M QTLB-24D-SP-6T QTLB-24D-SPTweco 接头 Welding Gun c/w Tweco Fitting 8M QTLB-24D-SP-8T 후号 零件号 描述 序号 零件号 描述 LTF21180 Swan Neck 0° 直枪头 0° LGX2015 Bearing 轴套 17 LTF2245 Swan Neck 45° 弯枪头 45° 18 LTY2001 Press Arm Shaft 压板 LTX2001 GearBox Assembly 减速器总成 19 LGX2012 Press Arm Spring 压臂弹簧 LTF2111 Straight Conductor Tube 直枪颈 20 LGX2011 Press Arm Bolt 压紧螺栓 LTF2112 Goose Conductor Tube 弯枪颈 21 EJ0003 Trigger Switch 扳机 Pin Head Tube 导电接头内芯 LTX2011 22 LGH2011 Cover,Drive Roll 透明罩 Contact Adaptor 导电接头 LTX2012 23 LTH2101 Handle 前手柄 Gas Connector 接头气嘴 LTX2013 Cable Clamp 电缆压板 24 LTH2111 Nut 螺母 LGF2111 25 Spool Cover Assembly 焊丝盘总质 LTT2001 Potentiometer Housing 电位器固定板 LTZ2012 Spool Defence Shell 焊丝盘罩 26 LTT2016 LTZ2013 WFS Control Knob 电位器控制旋钮 27 9 LTT2015 Spool Shaft 焊丝盘轴 10 LTH2112 Nut, Handle 枪壳锁母 28 LMT2014 Bushing Resisitance Rubber 阻尼套 11 LGX2018 Key 半圆键 29 LMT2013 Location Bushing 定位套 Drive Roll (0.8/0.9mm) 送丝轮 (0.8/0.9mm) 12 LGX2019 30 LMT2012 Adjusting Nut 调节螺母 LGX2020 Drive Roll 1.2mm 送丝轮 1.2mm 31 Locking Screw 固定螺栓 LMT2011 Potentiometer 10KΩ 电位器 10KΩ 13 Q8210\* Cable Assembly 6m 电缆总成 6m 32 LTL2060L Potentiometer 5KΩ 电位器 5KΩ Q8205 33 SS5201 Backing Spring Cable Support 后弹簧护套 Q8201 Potentiometer 1KΩ 电位器 1KΩ SH5201 Back Handle 后枪壳 34 14 LZ3601 Motor 电机 35 EP3001 Gun Plug Nut 插件锁母 LTX2015 Clamp 焊丝盘夹紧块 15 36 MV0010 10 Pin Connector 10 芯插头 16 LGX2016<sup>3</sup> Push Roll (0.8/0.9mm) 送丝轮 (0.8/0.9r 37 LTU2003 Euro Gun Plug 欧式插头 LGX2017 Push Roll 1.2mm LTR21134\* Liner,Use With Swan Neck 180°, 导丝簧, 枪颈 180° 38 LTR21142 Liner,Use With Swan Neck 45°, 导丝簧用于枪颈 45° 33 34 37 Denotes Standard Build 表示标准配置,选配件须注明编号



# **SECTION 6** – PUSH-PULL TORCH: Installation and Operation

### 6.01 PUSH-PULL: Environmental Limits

Air-Cooled, and Water-Cooled MIG/MAG Manual Welding Torches are designed for use in environments where:

- Operating temperature range is -10 °C to +40 °C (+14 °F to +104 °F)
- Relative air humidity during operating is 0% to 90% @ + 20 °C ambient air temperature

### 6.02 PUSH-PULL: Operation Guidelines

Be sure to locate the MIG/MAG equipment according to the following guidelines:

- In areas, free from moisture and dust.
- In areas, free from oil, steam, and corrosive gases.
- In areas, not subjected to abnormal vibration or shock.
- In areas, not exposed to direct sunlight or rain.



# PUSH-PULL TORCH: Installation and Operation



# PUSH-PULL TORCH: Installation and Operation





7.02 PUSH-PULL: Nozzles, Contact Tips, Contact Tip Holders, Gas Diffusers, and Liners Parts



7.02 PUSH-PULL: Nozzles, Contact Tips, Contact Tip Holders, Gas Diffusers, and Liners Parts

C	CONTACT	TIPS HO	OLDERS								
							PG <sup>1</sup>	4000 5000 B 240 PN 5001 B 211 P	360	Product picture	
j	Part Number FSC5001	Shape	Material CuCrZr	A mm M10x1.25	B mm M12x1	C mm 32				A C B	
	EC2001		Brass	M6	M6	25.5					
	EC3002	-	Brass	M8	M8	32					
D	GAS DIFF	USERS									
	Part Number	Shape	Mater`al	A mm	B mm	C mm	PG	4000 5000 B 240 OTLE OTLE	,36 <sup>D</sup>	Product picture	
	FSD5001	-	phenolic	M16x1	-	28.5				A B	
	ED2001	-	ceramic	-	-	20					
	ED3002	-	DMC	-	-	32.5		•			
E.	LINERS										
	Part Number		Material	N're S'ze ⊕∆in /m	im Length R	ft motors	PG	4000 5000 B-240 PW 5000 DTLB 271P	360	Product picture	
I	LTR3412-6		Graphite	0.8-1.2	engu bi	8				0 A	
	LTR2210 6		Steel	0.8 1.0		6					
1	LTR2310-6		Teflon	0.8-1.0		6					
	LTR3212-6		Steel	1.0-1.2		6		•			
	LTR3312-6		Teflon	1.0-1.2		6					

### 7.03 PUSH-PULL TORCH QTLB-24D / QTLB-36D: Change Pressure Roll / Drive Roll





### **CHANGE Drive Roll (8)**

- a) Disconnect Power to the MIG/MAG equipment.
- b) Unscrew Handle Nut (1), Trigger Screw (11), Rear Handle Screw (12), and 3 x Handle Screws (2).
- c) Wiggle the **Handle Half (3)** away from the Torch Handle then towards the **Cable Assembly**.
- d) Unscrew and remove Screw (4) and Washer (5) from the Drive Shaft.
- e) Push down on the red Pressure Roll Release Button (10) then slide the Drive Roll (8) off the Drive Shaft. Do NOT lose the Drive Key (9).
- f) Fit a new Drive Roll (8) and then re-assemble the Push-Pull Torch. Note: Ensure the Drive Key (9) is fitted into the slot of the Drive Shaft then line up the slot in the Drive Roll (8) with the Drive Key (9).

### **CHANGE Pressure Roll (6)**

- a) Disconnect Power to the MIG/MAG equipment.
- b) Unscrew Handle Nut (1), Trigger Screw (11), Rear Handle Screw (12), and 3 x Handle Screws (2).
- c) Wiggle the **Handle Half (3)** away from the Torch Handle then towards the **Cable Assembly**.
- d) Push down on the red Pressure Roll Release Button (10) then unscrew the Screw (4) to remove the Washer (5), Pressure Roll (6), and Bearing (7) from the Pressure Mechanism. Do NOT lose the Bearing (7).
- e) Fit a new Pressure Roll (6) and then re-assemble the Push-Pull Torch.

7.04 PUSH-PULL TORCH PG4000 / PG4045, PW5000 / PW5045: Change Pressure Roll / Pressure Arm Assy





### CHANGE Drive Roll (8)

- a) Disconnect Power to the MIG/MAG equipment.
- b) Slide the Wire Drive Mechanism Cover (3) towards the back of the PUSH-PULL Torch.
- c) Release the **Tension Arm (10)** off the **Hook (7)** then move the Tension Arm away from the **Pressure Arm Assy (6)**.
- d) Unscrew and remove Nut (9) then remove the Drive Roll (8). Do NOT lose the Drive Key.
- e) Fit a new Drive Roll (8) and then re-assemble the Push-Pull Torch.
   Note: Ensure the Drive Key is fitted into the slot of the Drive Shaft then line up the slot in the Drive Roll (8) with the Drive Key.

### CHANGE Pressure Arm Assy (6)

- a) Disconnect Power to the MIG/MAG equipment.
- b) Slide the **Wire Drive Mechanism Cover (3)** towards the back of the PUSH-PULL Torch.
- c) Release the Tension Arm (6) off the Hook (7) then move the Tension Arm (6) away from the Pressure Arm Assy (6).
- d) Unscrew and remove Screw (11) then remove the Pressure Arm Assy (6).
- e) Fit a new **Pressure Arm Assy (6)** and then re-assemble the Push-Pull Torch.



### 7.06 PUSH-PULL TORCH QTLB-24D: Torch Parts





### 7.08 PUSH-PULL TORCH PG4000 / PG4045: Torch Parts

Мо	1 — wearp 5 —	arts page	3 10 2 9 10 10 10 10 10 10 10 10 10 10		4 15 16 14 22 14 14 22 15 16 37 -13 14 -26 -26 -26 -26 -26		
Des	cription 描述		Length 长度			Part Number 编号	
PG 4	000 直枪颈 欧式接到	÷.	6M			PG 4000-6	
Weld	ding Gun c/w Euro F	itting	8M			PG 4000-8	
PW 4	<b>4045</b> 弯枪颈 欧式接线	£	6M			PG 4045-6	
Weld	ding Gun c/w Euro F	itting	8M			PG 4045-8	
Cor	mpontents 部件	ŧ					
No. 홍문	Part Number 零件号	Descripti	ion	No. 序号	Part Number 全 愛件号	Description Description 描述	1
1	PWF51180	抽述 Swan No	ck ₩₩5000/₩₩4000 0% 百龄头 0%	20	PW75014	Insulation Washer,Motor 电机绝缘纸垫	
	PWF5145	Swan Ne	ck AW5000/AW4000 6 重枪头 6	21	LZ3001-42V	Motor and Gear Box (42V) 电机带减速器 (42V)	
2	FSX5212	Fixing Sle	eeve 喷嘴夹套		LZ3001	Motor and Gear Box (24V) 电机带减速器 (24V)	· •
3	FSX5211	Insulatio	n Ring 四氟套	22	PWZ5021	Push Roll 0.8-1.2mm 压丝轮 0.8-1.2mm	
4	PWF5111	Straight (	Conductor Tube 0° 直枪颈 0°	23	PWZ5023	Base Push Roll 压丝轮座	
	PWF5112	Goose Co	onductor Tube 45° 弯枪颈 45°	24	Q440212	Spring Pin 2x12 弹性销	
5	PGZ4000	Drive Uni	it,Air Cooled 送丝单元,空冷Cover	25	PWZ5022	Shaft, Push Roll 压丝轮轴	
6	PWH0103	枪壳护罩		26	EJ0003	Trigger Switch 扳机	30
7	PGU4101	Neck Ada	aptor,Air Cooled 枪颈接头,空冷	27	Q8322*	Potentiometer 22KΩ 电位器 22KΩ	30
8	PWZ5011	Bracket		20	Q8310	Potentiometer 10KΩ 电位器 10KΩ	
9 10	03106	Screw M4	<b>4X0</b> 緊打 M4Xb 健長 M6	28	PWH0104	Potentiometer Knob 电位器旋钮	
11	PWZ5012	Drive Rol	3款 ♀ M0 II 0 8-1 2mm 送丝轸	30	PGI 4080	Cable Assembly 8m 由缆兑成 8m	
12	Q230525G	Screw M5	<b>5x25</b> 螺钉 M5x25	31	HDH0202	Back Handle 后枪壳	
13	PWZ5015	Tension /	Arm 摆臂	32	EP3001	Gun Plug Nut 插件锁母	· •
14	Q270312G	Screw Ma	<b>3x12</b> 螺钉 M3x12	33	PGU4001	Euro Gun Plug Without Control 欧式插头不带控制线	
15	PWZ5020	Wire Inle	t Guide,Back 后引导嘴	34	EU1011	Nut M10x1 螺母 M10x1	
16	DL3003	Nut M12x	<b>1.25</b> 螺母 M12x1.25	35	FV0009	9 Pin Connector, Fronius 9 针矩形插头, Fronius	
17	PWZ5013	Insulatio	n Ring,Motor 电机绝缘套	36	MV0010	10 Pin Connector 10 芯插头	
18	PWZ5017	Press Arr	n 压臂	37	3012C-200	Liner,Use With Swan Neck 1 导丝簧用于枪颈	
* Deno	otes Standard Bulid #	6 長示标准配	35 — 32 34 33 34 33 34 33 34 32 34 32 34 32 34 32 34 32 32 34 32 32 34 32 32 34 32 32 34 32 32 34 33 33 32 32 32 32 32 33 33 32 32 32 32		31		

# 7.09 PUSH-PULL TORCH PW5000 / PW5045: Torch Parts

7.09 FU.			040			
		3		4		
1 —	1		\		- Company	
					6	
wear	; parts page	2 11			40 32	
		13		18 19		
-			5	17	0 3 mm	
5 —	00			- 25		
		12 20	13	29		
	789	10 11 2226				
		23				Li .
		20		<b>N</b>		and the second sec
		24		21		ALCON.
					0	1
		elti				
Model 型号 Description 描述	-	Length 长度	-	_	Part Number 编号	
DW 5000 百枌颈 欧式接	<u>st</u>	6M			PW 5000-6	
Welding Gun c/w Euro	Fitting	8M			PW 5000-8	
		6M			PW 5045-6	
PW 5045 弯枪颈 欧式接 Welding Gun c/w Euro	头 Fitting	014				
Compontanta 20	(/+	SM			PW 5045-8	
Nô. Part Number	⊤ Descriptic	n	No.	Part Number	Description Description	1.00
序号 零件号	描述		序号	零件号	描述	
1 PWF51180	Swan Nec	k AW5000/AW4000 0° 直枪头 0°	21	PWZ5017	Press Arm 压臂	
PWF5145	Swan Nec	k AW5000/AW4000 45° 弯枪头 45°	22	PWZ5016	Headless Screw M4X25.5 螺纹圆柱销	
2 FSX5212	Fixing Sle	eve 喷嘴夹套	23	PWZ5014	Insulation Washer,Motor 电机绝缘纸垫	
3 FSX5211	Insulation	1 Ring 四氟套	24	LZ3001-42V	Motor and Gear Box (42V) 电机带减速器 (42V)	
PWF5112	Goose Co	nductor Tube 45° 查检颈 45°Drive	25	LZ3001	Motor and Gear Box (24V) 电机带减速器 (24V) Push	
5 PWZ5000	Unit,Wate	r Cooled 送丝单元,水冷Cover	26	PWZ5021	Base Push Roll 压丝轮座	
6 PWH0103	枪壳护罩		27	Q440212	Spring Pin 2x12 弹性销	
7 Q516020	O-Ring 16	<b>x2</b> 0 形圈 16x2	28	PWZ5022	Shaft, Push Roll 压丝轮轴	33 —
8 Q508020	O-Ring 8x	2 0 形圈 8x2	29	EJ0003	Trigger Switch 扳机	
9 PWU5102	Pin, Head	d Tube 前引导嘴	30	Q8322*	Potentiometer 22KΩ 电位器 22KΩ	
10 PWU5101	Neck Adap	ptor,Water Cooled 枪颈接头,水冷		Q8310	Potentiometer 10KΩ 电位器 10KΩ	
11 Q3106	Bracket t	烁 す M b エカロ	31	PWH0104	Potentiometer Knob 电位器旋钮	
12 PW25011 13 02304166	Screw M4	x6 螺钉 M4x6	32	PWH0100	Cable Assembly 8m 由缆兑成 8m	
14 PWZ5012	Drive Roll	.0.8-1.2mm 送丝轮	34	PWH0200	Back Handle 后枪壳	
15 Q230525G	Screw M5	<b>x25</b> 螺钉 M5x25	35	EP3001	Gun Plug Nut 插件锁母	
16 PWZ5015	Tension A	rm 摆臂	36	PWU5001	Euro Gun Plug Without Control 欧式插头不带控制线	
17 Q270312G	Screw M3	x12 螺钉 M3x12	37	EU1011	Nut M10x1 螺母 M10x1	
18 PWZ5020	Wire Inlet	Guide, Back 后引导嘴	38	FV0009	9 Pin Connector, Fronius 9 针矩形插头, Fronius	
19 DL3003	Nut M12x1	1.25 螺母 M12x1.25	39	MV0010	10 Pin Connector 10 芯插头	
20 PWZ5013	Insulation	n Ring, Motor 电机绝缘套	40	3012C-200	Liner,Use With Swan Neck 1 导丝簧用于枪颈	
		35	Te	34		1
		37			A. C.	Jan Barris
						A CONTRACTOR
						Charter -
	39	9		• 7		P4 .
		Refer to 38 Page 30 for 1				
		Torch Liner	1			
					* Denotes Standard Bulid 表示标准配置,选配件须注明编号	

# **SECTION 8 –** TROUBLESHOOTING

**NOTE:** Weld quality is dependent on the correct consumables, proper Torch position/angles, and Product maintenance.

Description	Possible Cause	Corrective Action
1. Spool Torch	A The welding wire is jammed against the Swan	A Bemove welding wire from Spool Torch, remove
Welding wire does not feed	Neck Liner due to the welding wire not being	any burrs on the welding wire then straighten
into the <b>Spool Torch</b> Drive	straight.	end and feed welding wire into the Spool Torch.
Rolls.	B The Spool Torch is not fitted with the correct	B Check then replace any incorrect size parts in the
	contact tip, Swan Neck Liner, and Drive Rolls	Spool Torch such as contact tip, Swan Neck
	for the wire diameter & wire material.	Liner, and Drive Rolls.
	C The contact tip is blocked with welding wire	C Blow out Swan Neck and Swan Neck Liner with
	debris OR the Liner is worn / filled with dirt	clean, dried compressed air UR replace the con-
	and debris.	Lact lip and the Swan Neck Liner.
	D Wrong size Swan Neck Liner.	welding wire
	F Worn or broken Spool Torch Trigger Switch.	F Test, if not working then replace
	F Wrong size/type feed rolls for welding wire or	F Change feed rolls to correct size/type for welding
	worn feed rolls in the Spool Torch.	wire or change worn feed rolls in the Spool
		Torch.
2. Push-Pull Torch:	A The Push-Pull Torch is not fitted with the cor-	A Check then replace any incorrect size parts in the
Welding wire does not feed	rect contact tip, Swan Neck Liner, Torch Cable	Push-Pull Torch such as contact tip, Swan Neck
into the <b>Push-Pull Torch</b>	Liner, and Drive Rolls for the wire diameter &	Liner, Torch Cable Liner, and Drive Rolls.
Drive Rolls and a <b>Birds</b>	Wire material.	P. Deplace the contact tip and/or Liner, blow out
MIG/MAG equipment Drive	the Liner is worn / filled with dirt and debris	Torch Neck Liner conduit with clean dried com-
Bolls		nressed air
	C Wrong size Push-Pull Torch Cable Liner and	C Change Push-Pull Torch Cable Liner and/or Swan
NOTE: A Birds Nest is a	Swan Neck Liner.	Neck Liner to correct size/type for the welding
tangle of welding wire at		wire.
the Drive Rolls when the	D Worn or broken Torch Trigger Switch	D Test, if not working then replace.
welding wire stops due an	E Wrong size/type feed rolls for welding wire or	E Change feed rolls to correct size/type for welding
obstruction in a Torch Liner	worn feed rolls in Push-Pull Torch and/or the	wire or change worn feed rolls in Push-Pull
while the Drive Rolls are	MIG/MAG equipment.	Forch and/or the MIG/MAG equipment.
Spinning. 3 Welding wire creates a	A The Push-Pull Torch is not fitted with the cor-	A Check then replace any incorrect size parts in the
Birds Nest at the MIG/MAG	rect Torch Cable Liner and Swan Neck Liner for	Push-Pull Torch such as Swan Neck Liner and
equipment Drive Bolls.	the wire diameter & wire material.	Torch Cable Liner.
- 4	B The welding wire is not entering the Push-Pull	B Make sure that the Push-Pull Torch is fixed into
Refer to 2. above for addi-	Torch due to the mis-alignment between the	the Push-Pull Torch Welding wire inlet guide.
tional information on <b>Birds</b>	Torch Cable Liner and the Wire Inlet Guide.	
Nest.	C Inadequate Pressure Arm force to the Drive	C Increase the Pressure Arm force to the Drive Roll
	Roll which causes the Welding Wire to slip on	by the <b>Pressure Arm Screw</b> .
A Tauch is softing a during the	the Drive Roll.	
4. Forch is getting extremely	A Contact tip or tip noider are not tightened	A make tighter using a suitable tool.
not.	B Cooling system is not cooling effectively	B Check then correct coolant flow, fluid level, or
	b booming system is not booming checkively.	cleanliness
	C Cooling system is not correctly connected.	C Check connections (coolant inlet and return).
	D Torch Cable connections loose or defective.	D Make Torch Cable / Swan Neck connections
		tighter.

# TROUBLESHOOTING

Description	Possible Cause	Corrective Action
5. Welding wire feeding prob-	A The MIG/MAG equipment is not compatible	A Ask an Authorized Distributor if a SPOOL Torch /
lems.	with the SPOOL Torch / PUSH-PULL Torch.	PUSH-PULL Torch Interface Kit is available for
	B Contact tip is worn	your Mig/MAG equipment
	C Torch Liner and/or Swan Neck Liner is worn /	C Check the Liner; blow it out with clean, dry com-
	dirty.	pressed air. If needed replace it.
	D Consumables used are not suitable for the	D Use recommended consumables for the welding
	F MIG/MAG equipment not set-up properly	F Check the feed rolls feed roll pressure and the
		spool brake are adjusted as stated by the
		MIG/MAG equipment's manual.
	F Welding wire is contaminated.	F Use a cleaning felt to clean welding wire in the
	G SPOOL Torch / PUSH-PULL Torch Drive Roll	G Change the SPOOL Torch / PUSH-PULL Torch
	groove size is a different size to the Welding	Drive Roll groove size to suit the Welding Wire
	Wire diameter.	diameter or change the Welding Wire diameter to
		suit the SPOOL Torch / PUSH-PULL Torch Drive
	H SPOOL Torch / PUSH-PULL Torch control	H Connect the Multi-Pin to the MIG/MAG equip-
	Multi-Pin Connector is not connected to the	ment.
<u> </u>	MIG/MAG equipment.	
6. Wire teed stops during welding	A weiding wire blockage in contact tip.	A Check for contamination/clogging, clean or re- place contact tip
wordning.	B Wire burns back into contact tip.	B Move the contact tip further away from the arc.
	C Groove worn in contact tip by welding wire.	C Replace contact tip.
7. Porosity in the weld metal.	A Turbulent shielding gas flowing to weld zone	A Clean the Torch consumables and use nozzle /
	caused by spatter build up inside hozzle of on das diffuser	gas diffuser anti-spatter spray.
	B Too low or extremely high shielding gas flow in	B Check flow using a gas flow meter then adjust
	the Torch.	gas flow rate from 10 LPM (indoors, no drafts)
	C Shielding gas supply contaminated or incorrect	up to 20 LPM (welding in drafts or outdoors).
	shielding gas used.	check for correct shielding gas to the Welding
		System.
	D Moisture or contamination on the welding wire	D Check the wire and the work piece, use less or
8 Welding arc:	A Contact tin is worn	A Change contact tip
- always varies length	B Wrong welding parameters.	B Check the MIG/MAG equipment setup parame-
- is unstable		ters then change parameters.
- is erratic	C Poor electrical connections in the welding cir-	C Check / tighten all electrical connections of the
	cuit.	work piece.
9. Welding wire burns back	A Incorrect arc voltage/ wire feed speed weld pa-	A Adjust arc voltage and/or wire feed speed param-
to contact tip	rameters for the welding wire wire/mate-	eters.
	B Frratic / unstable welding arc	B Befer to "6 Wire feed stops during welding " on
		page 38.
	C Incorrect contact tip stick-out length for re-	C Adjust nozzle / tip relationship.
	quired weld.	D. Adjust wire stick-out
	auired weld.	
	E Ground cable to work piece fault.	E Replace ground cables and/or connections.
10. Short contact tip life	A Contact tip size.	A Replace with correct contact tip size.
	rolls scoring wire.	b Unange leed rolls.
	C Exceeding Torch duty cycle.	C Replace with higher rated Torch.
11. Extreme spatter	A Incorrect arc voltage/ wire feed speed weld pa-	A Adjust arc voltage and/or wire feed speed param-
	rameters for the welding wire / material / Torch	eters.
	B Inadequate shjelding gas coverage	B Verify shielding gas coverage or gas mixture
	C Contaminated wire or work piece.	C Use a cleaning felt to clean welding wire in the
		MIG/MAG equipment and work piece.

# **SECTION 9 –** ROUTINE SERVICE and MAINTENANCE

							Je te	
Service / Mainte- nance must be per- formed by a suitably Trained and Qualified Tradesperson	Disconnect Input Power Sup- ply from Welding System be- fore performing maintenance on the system. Electric shock can kill	Hot parts can burn. Let the Torch cool down prior to doing maintenance work	Turn off air compres- sor, and release air pressure from sys- tem. Compressed air can injure or kill.	Welding wire can cause in- jury	Moving parts can cause in- jury	Flying metal or dirt can injure eyes	Improper installation can cause fire	Read User Manual



Damaged Swan Necks, Torches, or Cable Assemblies must not be used!

Known defects must be repaired by suitably Trained and Qualified Tradesperson prior using Torch.

# Schedule for Routine Maintenance / Inspection with Actions

Before Every Use	• Check torch, contact tip, nozzle, liner, cables, Wire Drive System, Worn Drive Roll, and overall equipment for damage. Replace any damaged components.		
Every 8 Hours of Use	• Change Contact Tip.		
Once per Day	<ul> <li>Visual inspect for damages on the Swan Neck, and Torch Cable Assembly.</li> </ul>		
Every 16 Hours of Use	• Use dry, clean compressed air to blow out the Liner but first re- move contact tip.		
Every 40 Hours of Use	<ul> <li>Remove the Liner and check for wear. Replace Liner if worn.</li> <li>Remove the Liner and check for dirt deposits. Use dry, clean compressed air to blow out the Liner but first remove contact tip. Replace Liner if dirt cannot be removed from Liner.</li> </ul>		
Once per Month (1 x 8 Hour Shift per Day) OR Twice per Month (2 x 8 Hour Shifts per Day) OR Three Times per Month (3 x 8 Hour Shifts per Day)	<ul> <li>Make sure that all screws are tightened.</li> <li>Inspect all connections and hoses for damages.</li> </ul>		

# SECTION 10 - CIRCUIT DIAGRAMS FOR SPOOL & PUSH-PULL TORCHES

**NOTE 4:** The **Multi-Pin Plugs** and **Pin Outs** for all SPOOL TORCHES & PUSH-PULL TORCHES must be compatible with the MIG/MAG equipment they will be connected too.

**NOTE 5**: The MIG/MAG equipment must have the control circuitry to drive the **DC MOTORS** in the SPOOL TORCHES & PUSH-PULL TORCHES. **NOTE 6**: The **Wire Speed Potentiometers** in the SPOOL TORCHES & PUSH-PULL TORCHES must be compatible with the MIG/MAG equipment control circuitry.

SPOOL TORCH QLBF-200 III & QLBF-185		24V DC Motor	PUSH-PULL TORCH QTLB-		24V DC Motor	
	é é	Torch Trigger		<u>م</u>	Torch Trigger	
SPOOL TORCH QTLB-24D & QTLB-36D		24V DC Motor			Wire speed Potentiometer	
	<u>مہ</u>	Torch Trigger		<─────────────────────────────────────	10K or 5K or 1K Ohms	
	<b>م م</b>				24V or 24VDC Motor	
	← Potentiometer ← 10K or 5K or 1K Ohms	PUSH-PULL TORCH PG4000 / PG4045 &	ې بې	Torch Trigger		
			PW5000 / PW5045		Wire speed Potentiometer 22K or 10K Ohms	



Jinan North Welding Tools Co Ltd The North of 308 National Highway, Daqiao Town, Tianqiao Zone, Jinan 250121, Shandong, China China Sales: 0531 8896 2089 International Sales: +86 531 8861 0336 sale@north-weld.com northweld.com Australia (Asia Pacific Enquiries) North Welding Pty Ltd 143 Bradman Street, Acacia Ridge QLD 4110 Australia Tel: +617 3344 6555 Fax: +617 3344 4222

Stay Connected



Jinan North Welding Tools Co Ltd



Jinan North Welding Tools Co Ltd

All Trademarks / Part Numbers printed in this catalogue are the property of their respective owners and are for reference purposes only. All Trademarks / Part Numbers are in no way connected or affiliated with Jinan North Welding Tools Co Ltd. Specification / Product Information / Product Appearance are subject to change without notice. Please refer to www.northweld.com for the most up-to-date data.